



## Zawór zwrotny sterowany



| Nr katalogowy         | Wymiary [mm] |   |      |    |      |    |
|-----------------------|--------------|---|------|----|------|----|
|                       | G            | B | L1   | L2 | L3   | CH |
| <b>ZSP/01/005/018</b> | 1/8          | 6 | 50   | 25 | 18,5 | 18 |
| <b>ZSP/01/005/014</b> | 1/4          | 8 | 50,5 | 25 | 20,5 | 18 |